



Linksys SPA-942 User's Guide

V1.0

vianet

LINKSYS[®]
A Division of Cisco Systems, Inc.


CISCO

Linksys SPA-942 User Guide

Contents

Linksys SPA-942 Overview	3
Using the Call Features of the Linksys SPA-942	4-5
Placing a Call	
Answering a Call	
Ending a Call	
Blind Transferring	
Warm Transferring	
Placing a Call on Hold	
Placing a Conference Call	
Call Forwarding	
Do Not Disturb	
Using the Voice Mail Features of the Linksys SPA-942	6-7
Accessing Voice Mail	
Recording Your Message	
Fast-Forwarding or Rewinding Messages	
Voice Mail Prompt Menu	
Accessing Voice Mail from Another Location	
Using Additional Features of the Linksys SPA-942	8
Using Call History	
Changing Your Settings	

Linksys SPA-942 Overview



The following list highlights some of the features that are available with your Linksys SPA-942 VoIP phone.

1. Handset
2. LCD screen which displays time, date, your phone number, caller ID, call status, and soft key tabs.
3. Voice Mail indicator light, blinks when the phone is ringing and remains lit to indicate new voice messages
4. Lines – Shows the lines available to dial from.
5. Soft keys: Enables you to activate any functions displayed along the bottom of the LCD. Keys change depending on status of phone
6. Navigation button
7. Mailbox button – Allows you to check your voice messages
8. Hold button: Places the active call on hold, resumes a call on hold, and switches between an active call and an incoming call or an active call and a call on hold.
9. Setup button: Displays a menu that provides access to phone logs, directories, settings, and services.
10. Volume button: Increases or decreases volume for the handset and speaker. Also controls the ringer volume (if on-hook).
11. Headset button – allows for the use of a headset
12. Speaker button – activates speakerphone
13. Mute button – mutes the microphone on your phone so the receiving party cannot hear you.
14. Keypad: Works exactly like the keypad on a traditional telephone

Using the Call Features of the Linksys SPA-942

Placing a Call

There are 2 options available to place a call:

- Lift the handset and dial the number.
- Dial the number and press the **"dial"** soft key.

Answering a Call

There are 2 options available to answer a call.

- Lift the handset.
- Press the **"Speakerphone"** key.

Ending a Call

- Hang up the Handset.

Blind Transferring

This feature allows you to transfer a call without speaking to the person you are transferring to.

- While on the call, press the **"right navigation"** button then press the **"bxfer"** key (this will place the caller on hold).
- Dial the 4 digit extension or the local or long distance number to which you want to transfer the call.
- Press the **"dial"** soft key to transfer the call.

Warm Transferring


This allows you to speak to the person you are transferring to prior to transferring the call.

- While on the call, press the **"xfer"** key (This will place the caller on hold).
- Dial the 4 digit extension or the local or long distance number to which you want to transfer the call.
- When the second line rings, wait for the party to answer the call, announce the caller press **"xfer"** again to connect the two parties.
- Hang up or end the call.

Placing a Call on Hold

While on the call:

- Press the **"hold"** button
- To return to the call, press the **"hold"** button again.



Placing a Conference Call

To establish a conference call for an existing call:

- Press the "**Conf**" soft key (this will automatically select a new line and place the other party on hold).
- Dial the 4 digit extension or the local or long distance number of the second party.
- When the second party answers, press the "**Conf**" soft key again and the first party will be added to the call.
- Repeat steps 1 through 3 to add additional parties to the conference call.

Call Forwarding

To start forwarding:

Press the "**cfwd**" soft key and enter the number you would like to forward to.

To stop forwarding:

Press the "**-cfwd**" soft key.


Do Not Disturb

To enable Do Not Disturb hit the "**dnd**" soft key

To disable Do Not Disturb hit the "**-dnd**" soft key

Using the Voice Mail Features of the Linksys SPA-942

Accessing Voice Mail

- Press 
- Enter your mailbox number which is your extension number.
- Enter your temporary password which is your extension number.
- At this time you may reset your password. Press 0 for Mailbox Options, then 4 and follow the prompts.

Recording Your Message

- Press the "**messages**" key below the LCD display.
- Enter your extension number.
- Enter your temporary password which is your extension number or last 4 digits of your phone number.
- At this time you may record your greeting. Press 0 for Mailbox Options, then 1 to record your Unavailable message, press 2 to record your Busy message.

Fast-Forwarding or Rewinding Messages

- To fast-forward a message while it is playing, press the pound (#) key. This will fast-forward your message in 3 second intervals.
- To rewind a message while it is playing, press the star (*) key. This will rewind the message in 3 second intervals.

Voice Mail Prompt Menu

Press 1 for new messages. After your message has played you may press:

- 5 to repeat the current message
- 6 to listen to the next message
- 7 to delete this message
- 8 to forward this message to another user
- 9 to save this message

Press 2 to change folders. Your folder options include pressing:

- 0 for new messages
- 1 for old messages
- 2 for work messages
- 3 for family messages
- 4 for friends messages
- # to cancel

Press 3 for advanced options (currently not available).

Press 0 for mailbox options. Your options include:

- 1 to record your unavailable greeting
- 2 to record your busy greeting.
- 3 to record your name.
- 4 to change your password.
- * to return to the main menu.

Accessing Voice Mail from Another Location

- Dial your office telephone number.
- Enter **8500**.
- Enter your mailbox number which is your extension number.
- Enter your password.

Using the Additional Features of the Linksys SPA-942

Using Call History

To access your Call History press  Select option 3 or "Call History" and press the "select" soft key


You will have the option to view the following call histories:

- Missed Calls
- Received Calls
- Placed calls

Select the Call History you would like to view by highlighting it (using the up and down arrow keys below the LCD display) and pressing "**Select**" at the bottom of the LCD display. By highlighting a specific call in the history you have the option of:

- Dialing
- Exiting the current menu

Changing Your Settings

By using the  button you also have the option of:

- Adjusting the contrast of the LCD display
- Changing the ring type
- Adjusting your call preferences

(Other features are available but may be managed by your Network Administrator.)